



# INFLUENCE® SHEET FLOORING

---

## PRODUCT SPECIFICATIONS

<b>Wearlayer:</b>	Urethane (Low Gloss)
<b>Nominal Wearlayer Thickness:</b>	.026" (0.66mm)
<b>Nominal Total Thickness:</b>	.086" (2.18mm)
<b>Widths:</b>	12' (3.6m)
<b>Standard Roll Size (Sq. Yds.):</b>	111 (93sq/m)
<b>Weight per Sq. Yd. (Lbs.):</b>	4.9 (2.6 kg)
<b>ASTM F-970 Static Load Limit:</b>	500 lbs/in <sup>2</sup> (35.15 kg/cm <sup>2</sup> )
<b>ASTM F 1303:</b>	Type I, Grade 1 and Type II, Grade 3, Class B
<b>HUD/FHA Minimum Property Standards:</b>	Meets Wearlayer Thickness Requirement
<b>ASTM E-648 Flooring Radiant Panel:</b>	Class 1

## INSTALLATION

<b>Use:</b>	Residential, Light Commercial and Commercial.
<b>Installation System:</b>	Residential - Full Spread or Glueless. Light Commercial and Commercial - Full Spread.
<b>Location:</b>	Below, on and above grade concrete, above grade plywood.
<b>Fitting:</b>	Freehand or pattern scribe.
<b>Adhesive:</b>	Domco DT-VinylBond™.
<b>Trowel Notch:</b>	1/32" (0.8mm) deep x 1/16" (1.6mm) wide x 1/32" (0.8mm) apart.
<b>Seam Method:</b>	Residential - Double-cut dry. Adhere seam area with Domco S860 Seam Tape. For multiple seams over plywood, use Domco S870 Floating Seam Tape. Commercial - Double-cut dry. Adhere with Domco DT-VinylBond™.
<b>Seam Sealer:</b>	Residential - Domco DT-65 Seam Sealer. Light Commercial and Commercial – Heat weld with matching 4mm Domco vinyl welding thread.

- Keep material rolled face out on a sturdy core until time of installation.
- Maintain room temperature, flooring and adhesive at 65°F (18°C) for 48 hours before, during and after installation.
- Use only hydraulic (portland) cement based patching and leveling compounds.
- Use a high quality embossing leveler when installing over approved existing flooring.
- Do not contaminate seam edges with adhesive.
- Roll flooring in both directions with a 75-100 lb. (34-45kg) sectional floor roller.
- Protect sealed seams from all traffic for a minimum of 3 hours.

## CARE AND MAINTENANCE

- Do not replace frequently moved furniture or allow heavy traffic for at least 24 hours.
- Never slide heavy furniture or appliances across the floor. Place plywood on the floor and move the object across the plywood.
- To minimize scratching and indentations, equip tables and chairs with proper floor protectors.
- Sweep or vacuum to remove loose dirt or debris that can scratch the floor.
- Wipe up all spills promptly with a damp cloth or mop.
- Wash floor with Domco SureShine® Floor Cleaner or equal neutral floor cleaner designed for sheet vinyl flooring.
- The use of non-staining mats can remove dirt and debris in the entryways and help prolong the life of the floor.

## RESIDENTIAL WARRANTY

- 20 Year Wear and Manufacturing Defects.
- 20 Year Rip, Tear and Gouge.
- 20 Year Moisture Stain.
- 20 Year Asphalt Stain.
- 20 Year Underlayment Panel Stain.

## COMMERCIAL WARRANTY

- 5 Year Wear and Manufacturing Defects.