



RUSTIC® SHEET FLOORING

RUSTIC® TRUTEX™ SHEET FLOORING

PRODUCT SPECIFICATIONS

Wearlayer:	47000 - PVC (Low Gloss) 47T00 - TruTex™ (Low Gloss)
Nominal Wearlayer Thickness:	.012" (0.3mm)
Nominal Total Thickness:	.065" (1.6mm)
Widths:	6' (1.8m) and 12' (3.6m)
Standard Roll Size (Sq. Yds.):	6' – 82 (68sq.m) 12' –165 (137sq/m)
Weight per Sq. Yd. (Lbs.):	2.4 (1.3kg)
ASTM F-970 Static Load Limit:	75 lbs/in ² (34 kg/cm ²)
ASTM F 1303:	Type I, Grade 3, Class A
HUD/FHA Minimum Property Standards:	Meets Wearlayer Thickness Requirement
ASTM E-648 Flooring Radiant Panel:	47000 - Class 1

INSTALLATION

Use:	Residential.
Installation System:	Full Spread or Glueless.
Location:	Below, on and above grade concrete, above grade plywood.
Fitting:	Freehand or pattern scribe.
Adhesive:	Domco DT-201 or DT-VinylBond™ .
Trowel Notch:	1/32" (0.8mm) deep x 1/16" (1.6mm) wide x 1/32" (0.8mm) apart.
Seam Method:	Double-cut wet. Adhere seam area with recommended adhesive. or Double-cut dry. Adhere seam area with Domco Seam Tape.
Seam Sealer:	Domco DT-50, DT-55 or DT-65 Seam Sealer.

- Keep material rolled face out on a sturdy core until time of installation.
- Maintain room temperature, flooring and adhesive at 65°F (18°C) for 48 hours before, during and after installation.
- Use only hydraulic (portland) cement based patching and leveling compounds.
- Use a high quality embossing leveler when installing over approved existing flooring.
- Do not contaminate seam edges with adhesive.
- Roll flooring in both directions with a 75-100 lb. (34-45kg) sectional floor roller.
- Protect sealed seams from all traffic for a minimum of 3 hours.

FLOOR PROTECTION AND MAINTENANCE

- Do not replace frequently moved furniture or allow heavy traffic for at least 24 hours.
- Never slide heavy furniture or appliances across the floor. Place plywood on the floor and move the object across the plywood.
- To minimize scratching and indentations, equip tables and chairs with proper floor protectors.
- Sweep or vacuum to remove loose dirt or debris that can scratch the floor.
- Wipe up all spills promptly with a damp cloth or mop.
- Wash floor with Domco SureShine® Floor Cleaner or equal neutral floor cleaner designed for sheet vinyl flooring.
- The use of non-staining mats can remove dirt and debris in the entryways and help prolong the life of the floor.

WARRANTY

- | | |
|---|-----------------------------------|
| • 10 Year Wear and Manufacturing Defects. | 10 Year Asphalt Stain. |
| • 10 Year Rip, Tear and Gouge. | 10 Year Underlayment Panel Stain. |
| • 10 Year Moisture Stain. | |